

cricut easypress™ SE

9 in x 9 in

22.9 cm x 22.9 cm

EN | User Guide (02)

PT | Guia do Usuário (08)

CHP180N4



Get to know your Cricut EasyPress™ SE



- | | |
|----------------------|---------------|
| 1 Power Button | 5 Time |
| 2 Temperature Button | 6 Go Button |
| 3 Temperature | 7 Heat Plate |
| 4 Time Button | 8 Safety Base |

2

INDICATOR LIGHTS

- | | | |
|--|--------------------|---|
| | Stand by | ▶ Orange Light:
Warming up

Green Light:
Reached set
temperature |
| | Activation
mode | |
| | Machine on | |

Always handle with care

- Before operating machine, read enclosed Important Safety Instructions.

CAUTION: Heat Plate (7) gets very hot during use. Always return to Safety Base (8) when not in use.



How to operate

- Plug into compatible wall outlet
- Press **Power Button (1)** to turn on/heat-up
- To set temperature, press **Temperature Button (2)**, use +/- to adjust
- To set time, press **Time Button (4)**, use +/- to adjust
- To start countdown, press **Go Button (6)**
- Press **Power Button (1)** to turn off
- Auto-off after 13 minutes of inactivity
- Always press on a sturdy, stable foundation
- Avoid pressing on heat-sensitive surfaces
- Protect your surface with Cricut pressing mat or thick bath towel
- Avoid seams, buttons, zippers & bumps
- Suitable for iron-on projects

Need help?

Visit cricut.com/help

Important safety instructions

READ AND SAVE THESE INSTRUCTIONS. READ THIS ENTIRE DOCUMENT PRIOR TO SETTING UP, OPERATING, AND SERVICING YOUR CRICUT EASYPRESS™ SE.

Please follow the enclosed instructions, online instructions, and other Cricut instructional materials.

In these Safety Instructions, the term “Machine” means Cricut EasyPress SE.



WARNING: Risk of Injury, Fire, and Electric Shock.

Operating Machine in a manner not prescribed in the enclosed instructions, online instructions, and other official Cricut materials may result in damage to Machine, property damage, injury, or even death.

Please note the following safety-related symbols that appear on Machine:



Attention. Alerts you to potential hazards. Please read and follow all instructions, warnings, and cautions.



Caution, Hot Surface. Machine operates at high temperatures. Machine heat plate is hot during use. DO NOT TOUCH.



For Indoor Use Only. Machine is to be used in dry indoor locations only.



Return Machine to Safety Base. Machine's high operating temperatures can cause burns, damage surfaces, and start fires. Always place Machine in Safety Base when not holding or using.



Refer to instruction manual/booklet and follow all instructions, warnings and cautions to avoid property damage, personal injury or death.

WARNING: Machine operates at high temperatures that can cause burns or other injury. Machine heat plate is hot during use. USE WITH EXTREME CAUTION.



CAUTION: Use in a well-ventilated area – vapors from heating process may be irritating to sensitive individuals. In case of skin irritation, immediately wash skin with soap and water; for contact with eyes, immediately flush with water. If irritation persists, seek medical attention.

CAUTION: Risk of electric shock. Do not open, modify, or otherwise tamper with Machine.

Always turn Machine OFF before plugging or unplugging from the electrical outlet. Never pull on the cord to disconnect Machine from the electrical outlet; instead, grasp the plug and pull to disconnect Machine.

WARNING: To provide continued protection against risk of electric shock, connect to properly grounded outlets only. Connect only to a power outlet that delivers power which is in accordance with the electrical ratings marked on your product. Do not use with extension cord. If an extension cord is necessary, a cord with min. ampere rating 13 A shall be used. A cord rated for less amperage can result in a risk of fire or electric shock due to overheating.

Before cleaning Machine, unplug from power outlet and allow to cool completely. Only clean with a soft cloth dampened with glass cleaner or water. Never use flammable liquid or solvents like acetone or nail polish remover. Do not allow children to perform cleaning or maintenance on Machine.

Do not immerse in water or use in wet conditions.

Machine is intended for household and indoor use only. While using Machine, follow these safe-use practices:

- Use Machine in a well-ventilated area where air temperature does not exceed 95°F (35°C);
- Be careful when using Machine near combustible or heat reactive materials;
- Do not apply heat to material longer than recommended;
- Always unplug Machine and allow it to cool down before storage;
- Ensure Machine and safety base are situated on a flat, stable surface;
- Do not leave Machine unattended when it is switched on; and
- Unplug Machine from outlet when not in use and before servicing or cleaning.

WARNING: Machine becomes hot during use. Young children should be kept away.

Machine is not intended for use by children 12 years of age and under; or by persons with reduced physical, sensory or cognitive capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of

Machine by a person responsible for their safety.

Children should be supervised to ensure that they do not play with Machine.

The power cord should be positioned so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).

Use care not to allow the cord to touch the heated surface. Coil the cord loosely when storing.

If the power cord is damaged, do not operate Machine.

Do not operate if Machine has been dropped and is damaged. If Machine or power cord are damaged, to avoid a hazard contact Cricut Member Care for resolution: cricut.com/contact or 1-877-727-4288

To avoid a circuit overload, do not operate machine on the same circuit with another high wattage appliance

SAVE THESE INSTRUCTIONS

LIMITED WARRANTY: See cricut.com/warranty, or write to manufacturer or authorized region representative at applicable address shown, for full terms and conditions.

FCC STATEMENT

The U.S. Federal Communications Commission (in 47 CFR 15.105) has specified that the following notices be brought to the attention of users of this product.

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pursuant to Part 15.21 of the FCC Rules, any changes or modifications to this equipment not expressly approved by Cricut may cause harmful interference and void the FCC authorization to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15

of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Product specifications: CHP180N4	
Size – Unit (Width x Length x Height)	24.86 cm x 24.86 cm x 10.27 cm; 9.79 in x 9.79 in x 4.04 in
Weight – Unit	4.18 lbs (1.9 kg)
Size – Unit + Stand (Width x Length x Height)	26.65 cm x 26.65 cm x 13.57 cm; 10.49 in x 10.49 in x 5.34 in
Weight – Unit + Stand	4.72 lbs (2.14 kg)
Power input (appliance inlet)	120-127V, 60 Hz; 1150-1288 W
External power supply	N/A

Conheça a sua Cricut EasyPress™ SE



- | | |
|------------------------|--------------------|
| 1 Botão Liga/Desliga | 4 Botão de Tempo |
| 2 Botão de Temperatura | 5 Tempo |
| 3 Temperatura | 6 Botão Avançar |
| | 7 Placa Térmica |
| | 8 Base de Proteção |

LUZES INDICADORAS

- | | | | |
|--|------------------|--------------------------|--|
| | Modo de espera | ▶ Luz Laranja: Aquecendo | |
| | Modo de ativação | | Luz Verde: Temperatura definida atingida |
| | Máquina ligada | | |

Sempre manuseie com cuidado

- Antes de operar a máquina, leia as instruções de segurança fornecidas.

- CUIDADO:** A placa térmica (7) esquenta muito durante o uso. Sempre que ela não estiver em uso, coloque-a de volta na base de proteção (8).



Como funciona

- Ligue-a em uma tomada compatível
- Pressione o **Botão Liga/Desliga (2)** para ligar
- Para definir a temperatura, pressione o **Botão de temperatura (2)** e use +/- para ajustar
- Para definir o tempo, pressione o **Botão de tempo (4)** e use +/- para ajustar
- Para iniciar a contagem regressiva, pressione o **Botão Avançar (6)**
- Pressione o **Botão Liga/Desliga (2)** para ligar
- Desliga automaticamente após 13 minutos de inatividade
- Sempre trabalhe em uma base firme e estável
- Evite usar a prensa em superfícies sensíveis ao calor
- Proteja a superfície com uma base para prensa da Cricut ou uma toalha de banho grossa
- Evite costuras, botões, dobras e zíperes
- Adequado para projetos de vinil termocolante Iron-On

Precisa de ajuda?

Acesse cricut.com/pt-br/help

Instruções de segurança importantes

LEIA E GUARDE ESTAS INSTRUÇÕES. LEIA TODO ESTE DOCUMENTO ANTES DE CONFIGURAR, OPERAR E FAZER A MANUTENÇÃO DA SUA CRICUT EASYPRESS™ SE.

Siga as instruções fornecidas, as orientações online e outros materiais informativos da Cricut.

Nestas instruções de segurança, o termo “máquina” se refere à Cricut EasyPress SE.



ATENÇÃO: Risco de ferimentos, incêndio e choque elétrico.

Usar a máquina sem seguir as instruções fornecidas, as orientações online e outros materiais oficiais da Cricut pode resultar em danos à máquina, danos materiais, além de ferimentos e, até mesmo, morte.

Observe os seguintes símbolos relacionados à segurança que aparecem na máquina:



Atenção. Alerta sobre possíveis riscos. Leia e siga todas as instruções, avisos e precauções.



Caution, Hot Surface. A máquina funciona com temperaturas altas. A placa térmica da máquina fica quente durante o uso. **NÃO TOQUE.**



Para uso apenas em ambientes internos. A máquina deve ser usada apenas em ambientes internos secos.



Retorne a máquina para a base de proteção. As altas temperaturas de operação da máquina podem causar queimaduras, danificar superfícies e iniciar incêndios. Sempre coloque a máquina na base de proteção quando não estiver segurando ou usando a máquina.



Consulte o manual de instruções e siga todas as orientações, avisos e precauções para evitar danos materiais, ferimentos corporais ou morte.



AVISO: A máquina opera em altas temperaturas que podem causar queimaduras ou outros ferimentos. A placa térmica da máquina fica quente

durante o uso. **USE COM MUITO CUIDADO.**

CUIDADO: Use a máquina em uma área bem ventilada. Os vapores do processo de aquecimento podem causar irritação em pessoas mais sensíveis. Em caso de irritação na pele, lave a área com água e sabão imediatamente. Se houver contato com os olhos, lave imediatamente com água. Se a irritação persistir, procure assistência médica.

CUIDADO: Risco de choque elétrico. Não abra, modifique ou adultere a máquina.

Sempre **DESLIGUE** a máquina antes de ligá-la ou desligá-la da tomada. Nunca puxe o cabo para desligar a máquina da tomada. Em vez disso, segure o conector e puxe para desligar a máquina.

AVISO: Para proteção contínua contra o risco de choque elétrico, ligue a máquina apenas a tomadas devidamente aterradas. Ligue-a apenas a uma tomada que forneça energia de acordo com as classificações elétricas informadas no seu produto. Não use a máquina com cabo de extensão. Se você precisar de um cabo de extensão, use um cabo com corrente de no mínimo 13 A. Um cabo com corrente menor pode resultar em risco de incêndio ou choque elétrico devido ao superaquecimento.

Antes de limpar a máquina, desligue-a da tomada e deixe-a esfriar completamente. Limpe apenas com um pano macio umedecido com produto para limpeza de vidros ou água. Nunca use líquidos inflamáveis ou solventes como acetona ou removedor de esmalte. Não permita que crianças limpem ou façam a manutenção da máquina.

Não mergulhe a máquina na água ou use-a se ela estiver úmida.

A máquina é destinada apenas para uso doméstico e em ambientes internos. Ao usar a máquina, siga estas práticas de uso seguro::

- Use a máquina em uma área bem ventilada onde a temperatura ambiente não exceda os 35 °C (95 °F);
- Tenha cuidado ao usar a máquina perto de materiais combustíveis ou que podem reagir ao calor;
- Não aplique calor ao material por mais tempo do que o recomendado;
- Sempre desligue a máquina da tomada e deixe-a esfriar antes de guardá-la;
- Certifique-se de que a máquina e a base de proteção estejam posicionadas em uma superfície plana e estável;

- Não deixe a máquina sem supervisão quando ela estiver ligada; e
- Desligue a máquina da tomada quando ela não estiver em uso e antes de fazer sua manutenção ou limpeza.

AVISO: A máquina fica quente durante o uso. Mantenha-a longe de crianças pequenas.

A máquina não deve ser utilizada por crianças com 12 anos ou menos ou por pessoas com capacidades físicas, sensoriais ou cognitivas reduzidas, ou que tenham pouca experiência e conhecimento, a menos que tenham recebido supervisão ou instruções sobre o uso da máquina por uma pessoa responsável pela sua segurança.

Crianças devem ser supervisionadas para garantir que não brinquem com a máquina.

Não deixe o cabo de alimentação pendurado na bancada ou mesa, evitando que alguém tropece, fique preso ou puxe-o acidentalmente (especialmente crianças).

Certifique-se de que o cabo não toque a superfície aquecida. Ao guardar, não enrole muito o cabo.

Se o cabo de alimentação estiver danificado, não ligue a máquina.

Não ligue a máquina se ela tiver caído e estiver danificada. Se a máquina ou o cabo de alimentação estiverem danificados, entre em contato com o Atendimento da Cricut para evitar riscos e receber ajuda: cricut.com/pt-br/contact ou 1-877-727-4288

Para evitar uma sobrecarga de circuito, não opere a máquina no mesmo circuito com outro aparelho de alta potência.

GUARDE ESTAS INSTRUÇÕES

GARANTIA LIMITADA: Consulte cricut.com/pt-br/warranty ou envie uma comunicação por escrito ao fabricante ou representante autorizado da região no endereço aplicável exibido para obter todos os termos e condições.

Importador: Brasil Inter Comex
Electronicos e Informatica LTDA

R. Sandata Ifigênia, 348 - Centro Historico
de São Paulo, São Paulo-SP, 01207-000

CNPJ: 17642282/0001-23

Especificações do produto: CHP180N4	
Tamanho – Unidade (largura x comprimento x altura)	24.86 cm x 24.86 cm x 10.27 cm; 9.79 in x 9.79 in x 4.04 in
Peso – Unidade	1.9 kg (4.18 lbs)
Tamanho – Unidade + Suporte (largura x comprimento x altura)	26.65 cm x 26.65 cm x 13.57 cm; 10.49 in x 10.49 in x 5.34 in
Peso – Unidade + Suporte	2.14 kg (4.72 lbs)
Entrada de energia (entrada do aparelho)	120-127V, 60 Hz; 1150-1288 W
Fonte de alimentação externa	Não se aplica



CHP184B4

100V; 799W; 50/60 Hz

CHP180A4

120-127V; 1150-1288W; 60 Hz

CHP180N4

CHP182F4

CHP182G4

CHP182I4

CHP182M4

220-240V; 50/60 Hz;
1052-1252W



CRICUT, INC. 10855 SOUTH RIVER FRONT PKWY, SOUTH JORDAN, UT 84095 USA

EC **REP**

CRICUT GERMANY GMBH, BLEICHSTR. 8-10, 40211 DÜSSELDORF, GERMANY

UK **REP**

CRICUT, UK LIMITED, 5 NEW STREET SQUARE, LONDON, UNITED KINGDOM, EC4A 3TW