

cricut easypress™ SE

9 in x 9 in

22.9 cm x 22.9 cm

EN | User Guide (02)

JP | ユーザーガイド (08)

CHP184B4



Get to know your Cricut EasyPress™ SE



- 1 Power Button
- 2 Temperature Button
- 3 Temperature
- 4 Time Button
- 5 Time
- 6 Go Button
- 7 Heat Plate
- 8 Safety Base

2

INDICATOR LIGHTS

- Stand by
- Activation mode
- Machine on
- Orange Light: Warming up
- Green Light: Reached set temperature

Always handle with care

Before operating machine, read enclosed Important Safety Instructions.

CAUTION: Heat Plate (7) gets very hot during use. Always return to Safety Base (8) when not in use.



How to operate

- Plug into compatible wall outlet
- Press **Power Button (1)** to turn on/heat-up
- To set temperature, press **Temperature Button (2)**, use +/- to adjust
- To set time, press **Time Button (4)**, use +/- to adjust
- To start countdown, press **Go Button (6)**
- Press **Power Button (1)** to turn off
- Auto-off after 13 minutes of inactivity
- Always press on a sturdy, stable foundation
- Avoid pressing on heat-sensitive surfaces
- Protect your surface with Cricut pressing mat or thick bath towel
- Avoid seams, buttons, zippers & bumps

Need help?

Visit cricut.com/help

Important safety instructions

READ AND SAVE THESE INSTRUCTIONS. READ THIS ENTIRE DOCUMENT PRIOR TO SETTING UP, OPERATING, AND SERVICING YOUR CRICUT EASYPRESS™ SE.

Please follow the enclosed instructions, online instructions, and other Cricut instructional materials.

In these Safety Instructions, the term "Machine" means Cricut EasyPress SE.

WARNING: Risk of Injury, Fire, and Electric Shock.

Operating Machine in a manner not prescribed in the enclosed instructions, online instructions, and other official Cricut materials may result in damage to Machine, property damage, injury, or even death.

Please note the following safety-related symbols that appear on Machine:

Attention. Alerts you to potential hazards. Please read and follow all instructions, warnings, and cautions.



Caution, Hot Surface. Machine operates at high temperatures. Machine heat plate is hot during use. DO NOT TOUCH.



For Indoor Use Only. Machine is to be used in dry indoor locations only.



Return Machine to Safety Base. Machine's high operating temperatures can cause burns,

damage surfaces, and start fires. Always place Machine in Safety Base when not holding or using.



Refer to instruction manual/booklet and follow all instructions, warnings and cautions to avoid property damage, personal injury or death.

WARNING: Machine operates at high temperatures that can cause burns or other injury. Machine heat plate is hot during use. USE WITH EXTREME CAUTION.



CAUTION: Use in a well-ventilated area – vapors from heating process may be irritating to sensitive individuals. In case of skin irritation, immediately wash skin with soap and water; for contact with eyes, immediately flush with water. If irritation persists, seek medical attention.

CAUTION: Risk of electric shock. Do not open, modify, or otherwise tamper with Machine.

Always turn Machine OFF before plugging or unplugging from the electrical outlet. Never pull on the cord to disconnect Machine from the electrical outlet; instead, grasp the plug and pull to disconnect Machine.

WARNING: To provide continued protection against risk of electric shock, connect to properly grounded outlets only. Connect only to a power outlet that delivers power which is in accordance with the electrical ratings marked on your product. Do not use with extension cord. If an extension cord is necessary, a cord with min. ampere rating 13 A shall be used. A cord rated for less amperage can result in a risk of fire or electric shock due to overheating.

Before cleaning Machine, unplug from power outlet and allow to cool completely. Only clean with a soft cloth dampened with glass cleaner or water. Never use flammable liquid or solvents like acetone or nail polish remover. Do not allow children to perform cleaning or maintenance on Machine.

Do not immerse in water or use in wet conditions.

Machine is intended for household and indoor use only. While using Machine, follow these safe-use practices:

- Use Machine in a well-ventilated area where air temperature does not exceed 95°F (35°C);
- Be careful when using Machine near combustible or heat reactive materials;
- Do not apply heat to material longer than recommended;
- Always unplug Machine and allow it to cool down before storage;
- Ensure Machine and safety base are situated on a flat, stable surface;
- Do not leave Machine unattended when it is switched on; and
- Unplug Machine from outlet when not in use and before servicing or cleaning.

WARNING: Machine becomes hot during use. Young children should be kept away.

Machine is not intended for use by children 12 years of age and under; or by persons with reduced physical, sensory or cognitive capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of

Machine by a person responsible for their safety.

Children should be supervised to ensure that they do not play with Machine.

The power cord should be positioned so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).

Use care not to allow the cord to touch the heated surface. Coil the cord loosely when storing.

If the power cord is damaged, do not operate Machine.

Do not operate if Machine has been dropped and is damaged. If Machine or power cord are damaged, to avoid a hazard contact Cricut Member Care for resolution: cricut.com/contact or 1-877-727-4288

To avoid a circuit overload, do not operate machine on the same circuit with another high wattage appliance

SAVE THESE INSTRUCTIONS

LIMITED WARRANTY: See cricut.com/warranty, or write to manufacturer or authorized region representative at applicable address shown, for full terms and conditions.

FCC STATEMENT

The U.S. Federal Communications Commission (in 47 CFR 15.105) has specified that the following notices be brought to the attention of users of this product.

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pursuant to Part 15.21 of the FCC Rules, any changes or modifications to this equipment not expressly approved by Cricut may cause harmful interference and void the FCC authorization to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15

of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Product specifications: CHP184B4	
Size – Unit (Width x Length x Height)	24.86 cm x 24.86 cm x 10.27 cm; 9.79 in x 9.79 in x 4.04 in
Weight – Unit	4.18 lbs (1.9 kg)
Size – Unit + Stand (Width x Length x Height)	26.65 cm x 26.65 cm x 13.57 cm; 10.49 in x 10.49 in x 5.34 in
Weight – Unit + Stand	4.72 lbs (2.14 kg)
Power input (appliance inlet)	100V, 50/60 Hz; 799 W
External power supply	N/A

Cricut EasyPress™ SE を使いこなす



- | | |
|---------|-------------|
| 1 電源ボタン | 5 時間 |
| 2 温度ボタン | 6 実行ボタン |
| 3 温度 | 7 ヒートプレート |
| 4 時間ボタン | 8 セーフティーベース |

インジケータライト

- | | |
|--------------|-------------------|
| 待機中 | オレンジのライト: 予熱中 |
| アクティベーションモード | グリーンのライト: 設定温度に到達 |
| 電源オン | |

取扱いには常に注意してください

マシンを操作する前に、同封の「安全に関する重要な注意事項」をお読みください。

注意: ヒートプレート(7)は使用中非常に熱くなります。使用しない時は

必ずセーフティーベース(8)に戻してください。



操作方法

- 互換性のある壁のコンセントにプラグを差し込みます

- **電源ボタン(1)**を押して電源を入れます
- 温度を設定するには、**温度ボタン(2)**を押し、+/-を使用して調整します
- 時間を設定するには、**時間ボタン(4)**を押し、+/-で調整します
- カウントダウンを開始するには、**実行ボタン(6)**を押します
- **電源ボタン(1)**を押してオフにします
- 操作をしないと、13分後に自動的に電源が切れます
- 必ずしっかりした安定した場所でプレスしてください
- 熱に弱い表面ではプレスしないでください
- Cricut プレスマットまたは厚手のバスタオルで表面を保護しましょう
- 縫い目、ボタン、ファスナー、突起部分を見て使用してください

お困りですか？

詳細は cricut.com/help をご確認ください

安全に関する重要な注意事項

説明書はお読みいただいた後、保存してください。CRICUT EASYPRESS™ SEの設定、操作、または点検を行う前に、この説明書を全てお読みください。

同封の説明書、オンライン説明書、その他のCricutの説明資料に従ってください。

これらの説明書での「マシン」という用語は、Cricut EasyPress SE を意味します。

警告: 怪我、火災、感電の危険があります。

同封の説明書、オンライン説明書、およびその他公式のCricut資料に規定されていない方法でマシンを操作すると、マシンの損傷、物的損害、負傷、さらには死亡につながる可能性があります。

マシンに表示される次の安全に関する図記号に注意してください:

注意. 潜在的な危険を知らせます。すべての指示、警告、注意をお読みになり、その内容に従ってください。

警告, 表面が高温になります. 本機は高温で作動します。使用中、本機のヒートプレートは熱くなります。触らないでください。

屋内使用専用. 本機は、屋内の乾燥した場所のみでご使用ください。



マシンをセーフティーベースに戻してください。本機の作業中の温度が高いと、火傷、表面の損傷、および発火の原因となる可能性があります。使用しない時は、必ず本機をセーフティーベースに置いてください。



物的損害、人身傷害または死亡を回避するため、取扱説明書及び小冊子を参照し、すべての指示、警告、注意に従ってください。

警告: 本機は高温で作動するため、火傷やその他の怪我をする可能性があります。使用中、本機のヒートプレートは熱くなります。細心の注意を払ってご使用ください。

注意: 換気の良い場所で使用してください。加熱時に発生する蒸気は、敏感な方には刺激となることがあります。皮膚炎が生じた場合は



直ちに石けんと水で皮膚を洗浄し、目に入った場合は直ちに水で洗い流してください。炎症が続く場合は、医師の診察を受けてください。

注意: 感電の危険があります。マシンを分解したり、改造したり、その他の方法で手を加えないでください。

コンセントからプラグを抜いたりする前に、必ず本機の電源をオフにしてください。マシンをコンセントから抜く際、電源コードを引っ張らず、プラグを持って引き抜いてください。

警告: 感電のリスクを常に回避するため、適切に

接地されたコンセントにのみ接続してください。マシンに表示されている電気定格に準拠した給電を行うコンセントにのみ接続してください。延長コードと一緒に使用しないでください。延長コードが必要な場合は、最小定格電流13Aのコードを使用してください。アンペア数の少ないコードを使用すると、過熱による火災や感電の危険があります。

本機のクリーニング前に、電源コンセントからプラグを抜き、完全に冷ましてください。クリーニングには、ガラスクリーナーまたは水で湿らせた柔らかい布でクリーニングしてください。可燃性の液体や、アセトンやマニキュアの除光液などの溶剤は絶対に使用しないでください。お子様がマシンのクリーニングやメンテナンスを行わないようにしてください。

水に浸したり、濡れた状態で使用したりしないでください。

マシンはご家庭でのみ、かつ屋内でのみご使用ください。マシンをご使用中は、次の安全な使用方法に従ってください:

- 気温が35°Cを超えない換気の良い場所で使用してください;
- 可燃性または熱反応性物質の近くでマシンを使用する場合は、ご注意ください;
- 推奨されている時間以上に、素材に熱を加えないでください;
- 使用後は必ずマシンのプラグを抜き、冷まし

てから収納してください;

- マシンとセーフティーベースが平らで安定した面に置かれていることを確認してください;
- 電源が入った状態でマシンを放置しないでください;
- 使用していない時や点検、クリーニングを行う前は、マシンの電源プラグをコンセントから抜いてください。

警告: マシンは使用中、高温になります。お子様の手が届かないようにしてください。

本機は12歳以下のお子様、または、身体的、感覚的、認知的能力が低下している方、または経験と知識が不足している方による使用を目的としたものではありません。使用するためには、安全責任者による本機の使用に関する指示や監督を受ける必要があります。

お子様がマシンで遊ばないように、しっかり監督してください。

電源コードは、つまずいたり、引っ掛かったり、(特にお子様が)不意に引っ張ったりする可能性のあるカウンタートップやテーブルの上に垂れ下がらないように配置する必要があります。

電源コードが加熱面に触れないように注意してください。収納時は電源コードをゆるめに巻いてください。

電源コードが破損している場合は、マシンを使用しないでください。

マシンが落下し、損傷した場合は操作しないでください。マシンまたは電源コードが損傷している場合は、危険を避けるため、Cricutメンバーケアまでお問い合わせください。お問い合わせ先: cricut.com/contact または 1-877-727-4288

回路の過負荷を避けるために、同じ回路で別の高ワット機器を操作しないでください*

この説明書を保管してください

制限付き保証: cricut.com/warranty, を参照するか、メーカーまたは該当する住所の正規販売代理店まで書面でお問い合わせください。

製品仕様: CHP184B4	
サイズ - 本体 (幅×奥行×高さ)	24.86 cm x 24.86 cm x 10.27 cm; 9.79 in x 9.79 in x 4.04 in
重さ - 本体	1.9 kg (4.18 lbs)
サイズ - 本体とスタンド (幅×奥行×高さ)	26.65 cm x 26.65 cm x 13.57 cm; 10.49 in x 10.49 in x 5.34 in
重さ - 本体とスタンド	2.14 kg (4.72 lbs)
電源入力 (機器側差込口)	100V, 50/60 Hz; 799 W
外部電源	該当なし

	
CHP184B4	100V; 799W; 50/60 Hz
CHP180A4	120-127V; 1150-1288W; 60 Hz
CHP180N4	
CHP182F4	220-240V; 50/60 Hz; 1052-1252W
CHP182G4	
CHP182I4	
CHP182M4	



CRICUT, INC. 10855 SOUTH RIVER FRONT PKWY, SOUTH JORDAN, UT 84095 USA

EC

REP

CRICUT GERMANY GMBH, BLEICHSTR. 8-10, 40211 DÜSSELDORF, GERMANY

UK

REP

CRICUT, UK LIMITED, 5 NEW STREET SQUARE, LONDON, UNITED KINGDOM, EC4A 3TW