




Pooh and Friends

Pooh et Amis



Use with all Cricut® machines
Pour être utilisé avec toutes
les machines Cricut®

Some characters are very detailed and will cut best with the Cricut Expression™ machine
Quelques caractères sont très détaillés et couperont mieux avec la machine Cricut Expression™



For complete instructions see your Cricut® user manual or visit www.cricut.com
Pour des instructions complètes veuillez vous référer au Manuel de l'Utilisateur Cricut® ou visiter le site www.cricut.com

Contents • Table des Matières

English

About this Cartridge	4
Quick Start Project	7

Français

Au Sujet de Cette Cartouche	9
Projet de Commencement Rapide	12

Icon Gallery	14
Galerie d'icônes	15

Contact Us	66
Contactez-nous	67

ABOUT THIS CARTRIDGE

What is **Real Dial Size**?



Real Dial Size
OFF



Real Dial Size
ON

All characters are measured from the lowest possible point to the highest. In Pooh and Friends, the Base characters are all the same height and the layers and shadows are designed to fit them proportionately. If **Real Dial Size** is selected, all characters will be cut according to the size specified.




What Are Creative Feature Keys?

The top three pairs of keys on the left panel are reserved for the Creative Feature effects of each set. These Features vary with each specific cartridge, providing greater versatility and thousands of options!

The Creative Feature keys included on the Pooh and Friends cartridge are **Layers: 1 and 2**, **Layers: 3 and 4**, **kon**, **Icon: Square/Circle**, **Shadow: Base/kon**, and **Blackout**.

To use a Creative Feature key, just select it prior to pressing the **CUT** button. The characters displayed on the screen will then be cut in the style of the selected Creative Feature. Due to their sizes and shapes, a Feature may not work with all shapes. Please refer to the Icon Gallery for Creative Feature details.




TIP: A Feature can be selected before or after a character has been selected, but before the **CUT** button is pressed. Once pressed, a Feature key will remain lit until it is turned off in one of the following ways: the Feature key is pressed a second time or the **Reset All** key is pressed.

How do **Layers** features work?

The **Layers** features create pieces that fit proportionately to both the Base (non-shift) shapes. Use the layers to make a fully detailed Disney character.

TIP: Some characters are very detailed and will cut best with the Cricut Expression™ machine.



Now you're ready to try a project!



Pooh and Friends Card

Spread some cheer with this colorful card made with your friends Tigger, Pooh, and Piglet.

Materials:

Cardstock: blue, light green, green, black, orange, red, pink, light pink, dark pink, brown, tan, light brown, golden yellow

Adhesive

Step One:
Create card base. Trim blue cardstock to 12" x 12" and fold in half to form 12" x 6" card. Trim light green cardstock to 12" x 2.25" and adhere to bottom of card front.

Step Two:
Create Tigger. Using Pooh and Friends cartridge and black cardstock, cut one 3" <Tigger2>. Using orange cardstock, press **Layers: 1 and 2** feature and cut one 3" <Tigger2> to cut head and paws. Using light yellow cardstock, press **Shift** and **Layers: 1 and 2** feature and cut one 3" <Tigger2-s> to cut face. Using pink cardstock, press **Layers: 3 and 4** feature and cut one 3" <Tigger2> to cut nose.



Step Three:

Create Pooh. Using black cardstock, cut one 3" <Pooh2>. Using golden yellow cardstock, press **Layers: 1 and 2** feature and cut one 3" <Pooh2> to cut face and paws. Using red cardstock, press **Shift** and **Layers: 1 and 2** feature and cut one 3" <Pooh2-s>.



Step Four:

Create Piglet. Using black cardstock, cut one 3" <Piglet2>. Using light pink cardstock, press **Layers: 1 and 2** feature and cut one 3" <Piglet2> to cut head and hooves. Using pink cardstock, press **Shift** and **Layers: 1 and 2** feature to cut one 3" <Piglet2> to cut ears and nose. Using dark pink cardstock, press **Layers: 3 and 4** feature and cut one 3" <Piglet2> to cut collar.



Step Five:

Create log and grass. Using black cardstock, cut one 3 1/4" <Log>. Using brown cardstock, press **Layers: 1 and 2** feature and cut one 3 1/4" <Log>. Using light brown cardstock, press **Shift** and **Layers: 1 and 2** feature and cut one 3 1/4" <Log-s> to cut interior. Using tan cardstock, press **Layers: 3 and 4** feature and cut one 3 1/4" <Log> to cut edge. Using green cardstock, press **Icon** feature and cut one 3" <Tigger3> to cut grass.

Step Six:

Adhere all characters as desired. Adhere to log and attach log to card front. Adhere grass to bottom right of log. Write greeting in top left corner with pen.

AU SUJET DE CETTE CARTOUCHE

Qu'est-ce que le **Real Dial Size** fait?
(Disque de Définition de la Taille Réelle)

Tous les caractères sont mesurés à partir du point le plus bas possible jusqu'au point le plus haut possible. Dans la cartouche Pooh et Amis, les caractères de Base ont tous la même hauteur et les fonctions couches et ombrage ont été conçues pour s'ajuster à ceux-ci proportionnellement. Si vous avez sélectionné le **Real Dial Size** (Disque de Définition de la Taille Réelle), tous les caractères seront coupés en accord avec la sélection du Disque de Définition de la Taille.



Real Dial Size
OFF
(Désactivé)



Real Dial Size
ON
(Activé)




Qu'est-ce qui les Touches des Fonctions Créatives font?

Les trois paires supérieures de touches au côté gauche du panneau sont réservés pour les effets des Fonctions Créatives incorporées dans chaque set. Ces fonctions varient avec chaque cartouche spécifique en fournissant une plus grande versatilité et mille d'options!

Les touches des Fonctions Créatives Boutons incluses dans la cartouche Pooh et Amis sont **Layers: 1 and 2** (Couches: 1 et 2), **Layers: 3 and 4** (Couches: 3 et 4), **kon** (lône), **Icon: Square/Circle** (lône: Carré/Cercle), **Shadow: Base/Icon** (Ombrage: Base/lône), et **Blackout** (Noircissement).

Pour utiliser une touche de Fonction Créative vous n'avez que la sélectionner avant de presser le bouton de **CUT** (Coupe). Les caractères indiquées sur l'écran seront découpées en suivant le style de la Fonction Créative sélectionnée. Étant donné leurs tailles et leurs formes, une Fonction pourrait ne fonctionner pas avec toutes les formes. Veuillez vous référer à la Galerie d'icônes pour obtenir une plus grande information sur les Fonctions Créatives.




CONSEIL PRATIQUE: On peut sélectionner une Fonction avant ou après avoir choisi des caractères, mais ceci doit être effectué avant de presser le bouton de **CUT** (Coupe). Une fois qu'on a pressé une touche de Fonction, celle-ci restera illuminée jusqu'à la désactiver d'une des manières suivantes: en pressant par seconde fois la touche de Fonction; ou en pressant la touche **Reset All** (Rétablir tout).

Comment est-ce que la fonction **Layers** (Couches) travaille-t-elle?

La fonction **Layers** (Couches) crée des pièces qui s'ajoutent proportionnellement à la forme de Base (touche **Shift** non activée). Employez les couches pour créer un personnage Disney avec tous ses détails.

CONSEIL PRATIQUE: Quelques caractères sont très détaillés et couperont mieux avec la machine Cricut Expression™.



Maintenant vous êtes prêt à vous lancer dans un projet!



Carte Pooh et ses Amis

Semez le bonheur avec cette carte coloré confectionné avec vos amis Tigger, Pooh, et Piglet.

Matériaux:

Carton: bleu, vert clair, vert, noir, orange, rouge, rose, rose-clair, rose foncé, brun, couleur marron clair, brun clair, jaune doré
Colle

Étape Un:
Pour créer la base de la carte. Taillez le carton bleu jusqu'à 12" x 12" et pliez-le en deux pour créer une carte de 12" x 6". Taillez le carton vert clair jusqu'à 12" x 2.25" et collez-le à la partie inférieure de l'avant de la carte.

Étape Deux:
Pour créer Tigger (Tigre). En utilisant la cartouche Pooh and Friends (Pooh et Amis) et du carton noir, coupez un <Tigger2> de 3". En utilisant du carton couleur orange, pressez la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Tigger2> de 3" pour obtenir la tête et les mains. En utilisant du carton jaune clair, pressez **Shift** (Touche de Majuscule) et **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Tigger2-s> de 3" pour obtenir le visage. En utilisant du carton couleur rose, pressez la fonction **Layers: 3 and 4** (Couches: 3 et 4) et coupez un <Tigger2> de 3" pour obtenir le nez.

Étape Trois:
Pour créer Pooh. En utilisant du carton noir, coupez un <Pooh2> de 3". En utilisant du carton jaune doré, pressez la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Pooh2> de 3" pour obtenir le visage et les mains. En utilisant du carton rouge, pressez **Shift** (Touche de Majuscule) et la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Pooh2-s> de 3".



Étape Quatre:

Pour créer Piglet (Porcelet) En utilisant du carton noir, coupez un <Piglet2> de 3". En utilisant du carton rose-clair, pressez la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Piglet2> de 3" pour obtenir la tête et les mains. En utilisant du carton rose, pressez **Shift** (Touche de Majuscule) et la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Piglet2> de 3" pour obtenir les oreilles et le nez. En utilisant du carton rose foncé, pressez la fonction **Layers: 3 and 4** (Couches: 3 et 4) et coupez un <Piglet2> de 3" pour obtenir le col.



Étape Cinq:

Pour créer le tronc d'arbre et le brin d'herbe. En utilisant du carton noir, coupez un <Log> (<Tronçon>) de 3 1/4". En utilisant du carton brun, pressez la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Log> (<Tronçon>) de 3 1/4". En utilisant du carton brun clair, pressez **Shift** (Touche de Majuscule) et la fonction **Layers: 1 and 2** (Couches: 1 et 2) et coupez un <Log> de 3 1/4" pour obtenir la partie intérieure du tronçon. En utilisant du carton couleur marron clair, pressez **Layers: 3 and 4** (Couches: 3 et 4) et coupez un <Log> (Tronçon) de 3 1/4" pour obtenir les bords du tronçon. En utilisant du carton couleur vert, pressez la fonction **Icon** (Icône) et coupez un <Tigger3> de 3" pour obtenir le brin d'herbe.



Étape Six:

Adhérez tous les caractères à votre goût. Adhérez-les au tronçon et collez le tronçon sur la partie avant de la carte. Collez le brin d'herbe sur la partie droite inférieure du tronçon. Ecrivez votre salutation avec un stylo dans le coin gauche de la carte.

In the Icon Gallery, you will find a diagram for every character on your cartridge. The color change indicates that the image on the upper right is created using the **Shift** key and the image on the lower left is created without **Shift**. Using the Icon Gallery, you can see at a glance which Creative Features are available to use with the character that you have selected. **Some characters are very detailed and will cut best with the Crkut Expression™ machine.**

Pooh and Friends Creative Features:

Layers: 1 and 2


Layers: 3 and 4

kon

kon: Square/Circle

Shadow: Base/kon

Blackout



Dans la Galerie d'icônes vous trouverez un diagramme pour chaque caractère de votre cartouche. Le changement de couleur indique que l'image qui se trouve dans l'extrémité supérieure droite a été créée en utilisant la touche **Shift** (Touche de Majuscule) et l'image située dans l'extrémité inférieur gauche a été créée sans utiliser la touche **Shift** (Touche de Majuscule). Au moyen de la Galerie d'icônes, vous pouvez immédiatement voir quelles Fonctions Créatives sont disponibles pour les utiliser avec la caractère que vous avez choisie. **Quelques caractères sont très détaillés et couperont mieux avec la machine Cricut Expression™.**

Fonctions Créatives de la Cartouche
Pooh et Amis:

Layers: 1 and 2 (Couches: 1 et 2)

Layers: 3 and 4 (Couches: 3 et 4)


kon (Icône)

kon: Square/Circle (Icône: Carré Cercle)

Shadow: Base/kon (Ombrage: Base/Icône)

Blackout (Noircissement)

* Not Available (Pas Disponible)





Pooh

<Pooh>



	Not Available	
 Layers: 1 and 2	Not Available	 Layers: 3 and 4
 Icon: Square/Circle		 Not Available
 Shadow: Base/Icon	 Blackout	



<Pooh I>



  Layers: 1 and 2	Not Available	 Icon
 Icon: Square/Circle	 Layers: 3 and 4	 Not Available
 Shadow: Base/icon	 Not Available	 Blackout



<Pooh2>



	 Layers: 1 and 2	Not Available	 Layers: 3 and 4	Icon
 Icon: Square/Cirde		Not Available	 Shadow: Base/Icon	Not Available
				Blackout



<Pooh3>





<Pooh4>



  Layers: 1 and 2	  Layers: 3 and 4	  Icon
  Icon: Square/Circle	  Shadow: Base/Icon	Not Available  Blackout



<Pooh5>



Layers:
1 and 2

Not Available

Not Available

Layers:
3 and 4



Icon



Icon:
Square/Circle



Shadow:
Base/Icon

Not Available



Blackout



<Poo hō>



 Layers: 1 and 2	 Not Available	 Not Available
 Icon: Square/Circle	 Not Available	 Layers: 3 and 4 Icon
	 Shadow: Base/Icon	 Not Available Blackout



<Pooh7>



Icon:
Square/Circle



Layers:
1 and 2



Not Available

Not Available

Layers:
3 and 4



Icon



Not Available



Shadow:
Base/Icon



Blackout



<PoohB>



Layers:
1 and 2

Not Available

Not Available

Layers:
3 and 4



Icon



Not Available



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout



<Pooh?>



		Not Available	
Layers: 1 and 2		Layers: 3 and 4	Icon
		Not Available	
Icon: Square/Circle		Shadow: Base/Icon	Blackout



Tigger

<Tigger>



Not Available



Layers:
1 and 2

Not Available

Layers:
3 and 4



Icon



Not Available



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout



<Tigger!>





<Tigger2>



Layers:
1 and 2



Layers:
3 and 4



Icon



Not Available



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout



<Tigger3>



Layers:
1 and 2

Not Available



Icon

Not Available



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout



<Tigger4>



Layers:
1 and 2



Icon:
Square/Circle

Not Available



Layers:
3 and 4

Icon

Not Available



Shadow:
Base/Icon



Blackout



<Tiger>



Layers:
1 and 2



Icon:
Square/Circle

Not Available



Layers:
3 and 4



Icon

Not Available



Shadow:
Base/Icon



Blackout



<Tigger>







<Tigger8>



Layers:
1 and 2



Icon:
Square/Circle



Not Available



Layers:
3 and 4

Icon

Not Available



Shadow:
Base/Icon



Blackout



<Lumpy>





Piglet

<Piglet>



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout



Layers:
1 and 2

Not Available

Not Available

Layers:
3 and 4



Icon

Not Available



<Piglet>





<Piglet2>



 Layers: 1 and 2	 Not Available	 Layers: 3 and 4 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	 Not Available Blackout



<Piglet3>



  Layers: 1 and 2	Not Available	  Icon
  Icon: Square/Cirde	  Shadow: Base/Icon	Not Available  Blackout



<Piglet4>



		Not Available 
	Layers: 1 and 2 	Layers: 3 and 4 
	Icon: Square/Cirde 	Not Available 
		Shadow: Base/Icon 
		Blackout



<Piglet5>



  Layers: 1 and 2	Not Available	 Layers: 3 and 4 Icon
  Icon: Square/Cirde	 Shadow: Base/Icon	 Not Available Blackout



<Piglet>



 Layers: 1 and 2	 Not Available	 Layers: 3 and 4 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	 Not Available Blackout



<Rabbit>



Icon:
Square, Circle



Layers:
1 and 2



Shadow:
Base/Icon



Blackout

Not Available



Icon

Not Available




<Owl>



 Layers: 1 and 2	 Layers: 3 and 4	 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	Not Available Blackout 



<Gopher>





Eeyore

<Eeyore>



Layers:
1 and 2



Icon:
Square/Circle



Not Available



Not Available

Layers:
3 and 4



Icon



Not Available



Shadow:
Base/Icon



Blackout



<Eeyore>





<Eeyore2>



			
	Layers: 1 and 2		Layers: 3 and 4
			
			Icon
			Not Available
Icon: Square/Circle			
		Shadow: Base/Icon	Blackout



<Eeyore3>



 Layers: 1 and 2	 Layers: 3 and 4	 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	Not Available  Blackout



<Eeyore4>



 Layers: 1 and 2	 Layers: 3 and 4	 Layers: 3 and 4	 Icon
 Icon: Square/Circle	 Icon: Square/Circle	 Shadow: Base/Icon	 Not Available



<Eeyore5>



 Layers: 1 and 2	 Layers: 3 and 4	 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	Not Available  Blackout



<Eeyore>



			
Layers: 1 and 2	Layers: 3 and 4	Layers: 3 and 4	Icon
			Not Available
Icon: Square/Circle	Shadow: Base/Icon	Shadow: Base/Icon	Blackout



<Roll>



Layers:
1 and 2



Not Available

Layers:
3 and 4



Icon

Not Available



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout




<Roo2>





<KangaRoo>





<100Acre>



Layers:
1 and 2



Layers:
3 and 4



Icon



Icon:
Square/Circle



Shadow:
Base/Icon



Not Available



Blackout





<TreeHous>



Layers:
1 and 2



Layers:
3 and 4



Icon



Icon:
Square/Circle



Shadow:
Base/Icon



Blackout

Not Available



<log>



  Layers: 1 and 2	Not Available  Layers: 3 and 4	  Icon
  Icon: Square/Circle	  Shadow: Base/Icon	Not Available  Blackout



<Bridge>



 Layers: 1 and 2	 Layers: 3 and 4	 Icon
 Icon: Square/Circle	 Shadow: Base/Icon	Not Available  Blackout



<Hive>



 	 	 
Layers: 1 and 2	Layers: 3 and 4	Icon
 	 	Not Available
Icon: Square/Circle	Shadow: Base/Icon	Blackout



<HunnyPot>





<FlwFme>



	Not Available	
	Not Available	
Layers: 1 and 2	Layers: 3 and 4	Icon
Icon: Square/Circle	Shadow: Base/Icon	Not Available
		
Blackout	Blackout	Blackout




<WoodFrame>



Not Available	Not Available	Not Available
Not Available	Not Available	Icon
Layers: 1 and 2	Layers: 3 and 4	Not Available
Icon: Square/Circle	Shadow: Base/Icon	Blackout



<LeafFrame>





< Snow Frame >



  Layers: 1 and 2	Not Available Not Available Layers: 3 and 4	  Icon
  Icon: Square/Circle	  Shadow: Base/Icon	Not Available  Blackout



For in-depth information about using your Cricut[®] cutting system refer to the User Manual included with your Cricut[®] machine. If you don't find the answers you need, support is available in the following two ways:

You will find the most current help and documentation on the web site. Find answers to FAQs and Troubleshooting problems any time of the day.

INTERNET: www.cricut.com

Refer to the Customer Support information that came with your Cricut[®] machine(s) or call for Customer Support options at:

PHONE: 1-877-7CRICUT (727-4288) Monday–Friday 9:00 a.m.–5:00 p.m., mountain time



Pour une information plus exhaustive sur comment utiliser le système de découpage Cricut[®] veuillez vous référer au Manuel de l'Utilisateur inclus avec votre machine Cricut[®]. Au cas où vous ne trouverez pas de réponse à vos questions, vous trouverez l'appui nécessaire à travers la manière suivante:

Vous trouverez l'aide et la documentation la plus mise à jour dans l'emplacement Web. Trouvez les réponses dans des Questions Fréquentes et dans Détection et Solution de Problèmes à tout moment du jour.

INTERNET: www.cricut.com



© 2007 Provo Craft and Novelty, Inc.
All rights reserved/Tous droits réservés
South Jordan, UT 84095
www.provocraft.com • 124407

© Disney

Based on the "Winnie the Pooh" works
by A.A. Milne and E.H. Shepard
Basé sur les œuvres de "Winnie the Pooh"
de A.A. Milne et E.H. Shepard
Visit the Disney Website at www.disney.com
Visitez le Site Web à www.disney.com

MADE IN CHINA/FABRIQUÉ EN CHINE

290535 Pooh and Friends

