

Use with CRICUT**
PERSONAL ELECTRONIC CUTTER**
and CRICUT EXPRESSION**



My Community™



By Brenda Birrell



Provo Craft

Contents

Meet the I	De	si	gı	ne	r									 	 			3
Advanced																		
Icon Galle	ry																	8
Contact U																		

My Community™









This handbook contains instructions specific to the My Community ™ cartridge. For complete instructions refer to the Cricut™ user manual included with your machine or visit www.cricut.com



The characters on the My Community" cartridge were designed by:

Brenda Birrell



I love life and know it is best when shared with family and friends by spending time together and being thankful for one another. Creating thoughtful cards and journaling scrapbooking memories will bring joy to your life and those around you as you create from your heart. Life can get crazy busy and that's why I was delighted

to create designs for the Cricut™ Personal Electronic Cutter™— to help simplify your life and keep projects quick and easy.

I feel very lucky to be able to play at work and the very best part is sharing the designs with you! I've been blessed to be surrounded by a special team of talented friends who share my dream of "simple creativity." Together we create images that will bring a smile to all of your paper projects.

Brenda Birrell is the founder of Pebbles in my Pocket and Pebbles Inc. She can be found with a camera in hand in Orem, Utah with her husband and five daughters. Just follow the flash!

ABOUT THIS CARTRIDGE

(This handbook contains instructions specific to the My Community" cartridge. For complete instructions refer to the Cricut" user manual included with your machine or visit www.cricut.com)

Selecting Characters

How to use the Shift and Shift Lock keys







To select a character from the upper right corner of a key, use the Shift key on the keypad. You don't need to hold it down. Just press Shift once and make your selection.



Use the Shift Lock key to select more than one character at a time from the upper right corners of keys. Press the Shift Lock key again to deselect it.

What is Real Dial Size?

Most Base characters are measured from the lowest possible point to the highest, but in My Community" the black (non-shifted) characters and the gray (shifted) characters are created at the same height. The Layers and Shadow features are sized proportionately to fit the Base characters. If Real Dial Size is selected, all characters will be cut according to the selected dial size.

There are three exceptions. Even if Real Dial Size is selected, the Train Engine, Coal Car, and Passenger Car are proportionate to the Caboose, the Grass is proportionate to the House, and all the Puzzle pieces are proportionate to the Foundation Puzzle piece. (Read more


about Foundation keys on page 7.)



Real Dial Size OFF



Real Dial Size ON




What Are Creative Feature Keys?

The top three pairs of keys on the left panel are reserved for the Creative Feature effects of each set. These Features vary with each specific cartridge, providing greater versatility and thousands of options!

The Creative Feature keys included on the My Community cartridge are Layers, Puzzle, Tile, Notebook, Shadow, and Blackout.


To use a Creative Feature key, just select it prior to pressing the CUT button. The characters displayed on the screen will then be cut in the style of the selected Creative Feature. Due to their sizes and shapes, a Feature may not work with all shapes. Please refer to the Icon Gallery for Creative Feature details.



TIP: A Feature can be selected before or after a character has been selected, but before the CUT button is pressed. Once pressed, a Feature key will remain lit until it is turned off in one of the following ways: the Feature key is pressed a second time or the Reset All key is pressed.

What Is a Foundation Key?


The My Community™ cartridge contains two Foundation keys with one character on the first key and two characters on the second key. Foundation shapes are the solid version of images that were used as Creative Features, or proportional images that Creative Feature keys can be used with.



7

In the Icon Gallery, you will find a diagram for every character on your cartridge. The color change indicates that the image on the upper right is created using the Shift key and the image on the lower left is created without Shift. Using the Icon Gallery, you can see at a glance which Creative Features are available to use with the character that you have selected. You will find that some characters are very detailed and cut better at a larger dial size.

My Community Creative Features Layers Puzzle Tile Notebook Shadow Blackout



<StryTime>





















nUp> Not


























Shadow


































Shadow

14.







Blackout













<GngrbdHs>



























Blackou

20

ebook Shadov















Puzzle





21





<OldLdySh>





























Blackout



Notebook

Layers













Puzzle





















Blackout

















Puzzle

Shadow
















Blackout























































Blacko

33













Puzzle




























www.cricut.com




























































www.cricut.com

45








www.wisten

47




















<Policemn>



























, b



www.cricut.con



















Puzzle























Shadow









www.cicut.com



































Shadow





Blackout







































For in-depth information about using your Cricut™ cutting system refer to the User Manual included with your Cricut™ machine. If you don't find the answers you need, support is available in the following two ways:

You will find the most current help and documentation on the web site. Find answers to FAQs and Troubleshooting problems any time of the day.

INTERNET: www.cricut.com

Refer to the Customer Support information that came with your Cricut" machine or call for Customer Support options at:

PHONE: 1-877-7CRICUT (727-4288) Monday-Friday 9:00 a.m.-5:00 p.m., mountain time





© 2007 Provo Craft and Novelty, Inc. South Jordan, UT 84095 All rights reserved / Tous droits réservés Made in China / Fabriqué en Chine www.provocraft.com • 0210007