


10. Working with text


I. Ungroup to Lines

Refine the design of your project by separating each row of text into its own layer. This makes it easy to rotate, resize, color, or delete individual rows of text without impacting the others.

Step 1 Click on the solid portion of text to select it. The Bounding Box will appear around the text.



Step 2 Click *Ungroup to Lines* in the Edit Bar. The lines of text are separated wherever there is a line break. Each line is converted to a separate image. The layers of each row will remain grouped.



Step 3 In the Layers Panel, the rows are grouped with their layers. Each row of text now can be moved, sized, and rotated separately.

