


# 15. Print then Cut

## B. Changing a standard image into a printable


The Cricut® Image Library is full of images and fonts that can easily be turned into Print then Cut images. Using the Flatten tool makes this easier than ever—just the click of a button, and you're ready to Print then Cut!

**Step 1** Select all the layers of the standard image you would like to Print then Cut.




**Tip** For the Flatten tool to become active, you must have more than one layer selected. To change a single layer to a print, you must change the line type to a print from the Layer Attributes Panel.

**Step 2** At the bottom of the Layers Panel, click *Flatten*.



**Step 3** The image now appears in the Layers Panel as a single image and has a Printer Icon as the line type, indicating that it will Print then Cut. You will notice the black outlines of the image on the design screen have disappeared, also indicating it is a printable.



*Tip* To make any edits to your flattened image, you first need to Unflatten the image using the Unflatten tool in the Layers Panel. This will open the Layer Attributes Panel, where you can change the line type and color of each layer.