


18. Purchasing images

A. Purchasing images and patterns from the mat preview


Design your project with ease using any image or pattern from Cricut Design Space™. There is no need to purchase images and patterns until you are ready to start cutting. Images and patterns can be purchased individually or in image sets, or purchase one of the subscription plans for access to over 25,000 images and fonts and over 800 patterns.

Step 1 From the mat preview screen, you'll see the total amount of your purchase in the bottom right corner. Click "PURCHASE."




Step 2 On the Purchase Summary screen, if you haven't already, enter your payment information. Once the information has been entered, the Save Profile button will become

active. Click "SAVE PROFILE" to continue. (If your payment information has been recorded, you will skip this step.)




Tip Cricut Design Space™ will save your information for future purchases. You can change your information in the Account Details screen at any time.

Step 3: Review your purchase summary and enter any promo or discount codes if applicable.



Step 4 Enter your password in the Authorize Purchase field, and then click "AUTHORIZE."



Step 5 Once your purchase is complete, you will be returned to the mat preview and a message will read, "Order Successful."

