



## How Do I

# Find the Current Version of Design Space?

*Cricut recommends using the latest version of your software for best results with your Cricut machine. You can find the steps for each platform through the steps below:*

To find the firmware version of your Cricut machine, please visit this [help article](#).




Note: Cricut DesignStudio is available only for Windows computers and has been discontinued permanently. Any cartridges released after April 11, 2013, will not be updated to appear in the Cricut DesignStudio software. Cricut Craft Room was shut down on July 16, 2018. Visit our blog for more information.



## Let's Start


### Windows:

1. Click on the arrow on the taskbar to show hidden icons.
2. Let your mouse hover over the Cricut Design Space icon.
3. The bridge version will appear.



## Mac:


1. Select the Cricut icon in the upper right corner of the screen.
2. Select **About**.
3. A small window will appear showing the current version.



## iOS:


### Cricut Design Space:

1. Open Cricut Design Space App and sign in.
2. Open your profile icon on the top-left (shows your initials).
3. The version number will be listed at the bottom of the menu.




## Cricut Basics:

1. Open Cricut Basics App.
2. Open the menu on top-left.
3. The version number will be listed at the bottom of the menu



## Android:

1. Open Cricut Design Space App and sign in.
2. Open your profile (person icon) on the top-left.
3. The version number will be listed at the bottom of the menu.





## Additional Resources

[Learn.cricut.com](https://learn.cricut.com)

[Help.cricut.com](https://help.cricut.com)

[Inspiration.cricut.com](https://inspiration.cricut.com)

[How do I find the current firmware version on my machine?](#)

[Firmware Update - Cricut Imagine, Expression 2, Gypsy](#)

[Firmware update failing or not completing \(Older Machines\)](#)

[Release Notes 2018-08-02](#)