


Adding

The Cricut Design Space™ app makes it easy to personalize your project using text and different fonts. You can use fonts from the Cricut® Image Library, the fonts installed on your iOS® device (iPad®, iPhone® and iPod Touch®), or both.

Step 1 Tap the Text button to insert a text box onto the design canvas and open the keyboard and Text Edit panel. A text edit field will open near the text box.



Adding

Step 2 Type your text in the text edit field and watch as it appears in the text box in the selected font and style.



Tips for working with text:

- The design canvas can be scrolled or zoomed in/out above the keyboard to show other images or text while you type. This is especially useful to see items hidden below the keyboard.
- Tapping outside of the field closes the text edit field and dismiss the keyboard and Text Edit panel. Double tapping on the text box opens the Text Edit panel.
- You can have more than one line of text inside a text box; create line breaks using the enter key on your keyboard.
- Text boxes can only contain one font; however, you can add as many text boxes to a project as you desire.
- Find text layers in the Layers panel by looking for a thumbnail of the first letter of the text.

Adding

For more information about working with text:

- Use the Text Edit panel to customize the font, alignment, size, letter, spacing, and more. See the other sections of the “Working with text” section of this manual for more information.
- The selected text box can be moved, rotated, and resized using any of the gestures, image manipulation handles, or tools in the Edit panel. Text boxes appear as an image group, meaning all letters and layers move and size together. See the “Working with images” section of this manual for more information.
- Use the Layers panel to select a line style (cut, draw, score, or print), change the color of the text, group text layers with other layers, arrange the order of layers, duplicate or delete text, and hide or unhide text layers. See the “Layers panel” section of this manual for more information.
- If you choose to draw (write) the text, the color options will change to match the colors of the available Cricut® pens. Cricut Design Space™ for iOS® devices (iPad®, iPhone® and iPod Touch®) will prompt you when to use your pen as you make your project. You must attach the drawing layer to another layer so that it appears on the correct cutting mat. See “Attaching & detaching” in the “Actions panel” section of this manual for more information.