

cricut Locker Talk™

By/Par: Brenda Birrell

Provo Craft

Contents • Table des Matières • Indice • Inhalt

English

Meet the Designer 4
Advanced Features 5
Quick Start Project 8

Français

Se retrouver avec le Dessinateur. 10
Fonctions Avancées 11
Projet de Commencement Rapide 14

Español

Encuentro con el Diseñador 16
Funciones Avanzadas 17
Proyecto de Iniciación Rápida. 20

Deutsch

Lernen Sie den Designer kennen 22
Erweiterte Features 23
Schnellstartprojek. 26

Icon Gallery 28
Galerie d'Icônes 29
Galería de Iconos 30
Bildergalerie 31

Contact Us 82
Contactez-nous 83
Contáctenos. 84
Verbinden Sie sich mit uns 85

For complete instructions see your Cricut™ user manual or visit www.cricut.com
Pour des instructions complètes veuillez vous référer au Manuel de l'Utilisateur Cricut™ ou visiter le site www.cricut.com
Para instrucciones detalladas refiérase a su Manual del Usuario Cricut™ o visite la página www.cricut.com
Finden Sie vollständige Anweisungen in Ihrem Cricut™ Benutzerhandbuch oder besuchen Sie www.cricut.com

The characters on the Locker Talk™ cartridge were designed by:

Brenda Birrell

I love life and know it is best when shared with family and friends by spending time together and being thankful for one another. Creating thoughtful cards and journaling scrapbooking memories will bring joy to your life and those around you as you create from your heart. Life can get crazy busy and that's why I was delighted to create designs for the Cricut™ cutting system—to help simplify your life and keep projects quick and easy.

I feel very lucky to be able to play at work and the very best part is sharing the designs with you! I've been blessed to be surrounded by a special team of talented friends who share my dream of "simple creativity." Together we create images that will bring a smile to all of your paper projects.

Brenda Birrell is the founder of Pebbles in my Pocket and Pebbles Inc. She can be found with a camera in hand in Orem, Utah with her husband and five daughters. Just follow the flash!

What is **Real Dial Size**?

All characters are measured from the lowest possible point to the highest. In Locker Talk™, all black (non shift) characters and all gray (shifted) characters are created at the same height. The Layers on the first creative feature key are sized proportionately to fit the Base characters. If Real Dial Size is selected, all characters will be cut according to the selected dial size.

Real Dial Size OFF

Real Dial Size ON



What Are Creative Feature Keys?

The top three pairs of keys on the left panel are reserved for the Creative Feature effects of each set. These Features vary with each specific cartridge, providing greater versatility and thousands of options!

The Creative Feature keys included on the Locker Talk™ cartridge are Layers, Phrase/Layers, Card, Book Cover, Shadow, and Blackout.

To use a Creative Feature key, just select it prior to pressing the CUT button. The characters displayed on the screen will then be cut in the style of the selected Creative Feature. Due to their sizes and shapes, a Feature may not work with all shapes. Please refer to the Icon Gallery for Creative Feature details.



TIP: A Feature can be selected before or after a character has been selected, but before the CUT button is pressed. Once pressed, a Feature key will remain lit until it is turned off in one of the following ways: the Feature key is pressed a second time or the Reset All key is pressed.

What is a Foundation Key?

Your Locker Talk™ cartridge contains three Foundation keys with two characters on each key. Foundation shapes are the solid version of images that were used as Creative Features, or proportional images that Creative Feature keys can be used with. These proportional images are Foundation/Companion shapes. Foundation shapes and Foundation/Companion shapes can be used alone or as layers using the Creative Feature keys. They can also be enhanced by adding shapes or phrases to them.





Now you're ready to try a project!

Book Cover Card

Celebrate the first day of school in style! Use the book cover foundation key to create this colorfully fun card.

Materials:

- Cardstock: red, yellow, green, blue, black, tan
- Patterned paper: coordinating colors
- Ribbon: 5/8"
- Adhesive
- Paper trimmer

Step One: Create message for front of card. Using black cardstock, press Shift and cut one 3" <1stday>.

Step Two: Using tan cardstock, press Shift and Layers feature and cut one 3" <1stday>. Repeat with red and green cardstocks.

Step Three: Using blue cardstock, press Shift and Blackout feature and cut one 3" <1stday>. Assemble layers.

Step Four: Create card from yellow cardstock using two book covers. Using yellow cardstock, press Shift and Blackout feature and cut two 4" <bkcover>.

Step Five: Position both book covers so that holes are on left side. Trim 1.5" off right side of one yellow book cover. Attach strip of patterned paper to second book cover along right edge. Lay trimmed book cover on top of large one, align holes, and tie together with ribbon. Adhere "first day of school" message to front of card extending off right edge so that it appears to overlap patterned paper.

In the Icon Gallery, you will find a diagram for every character on your cartridge. The color change indicates that the image on the upper right is created using the Shift key and the image on the lower left is created without Shift. Using the Icon Gallery, you can see at a glance which Creative Features are available to use with the character that you have selected. You will find that some characters are very detailed and cut better at a larger dial size.

Locker Talk™ Creative Features:

Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout



<1 st day>

<apple>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout



www.cricut.com

<busstop>

<busrear>



Layers

Phrase/Layers

Card

Book Cover



Shadow



Blackout

<glue>

<scissors>



<crayon2 >
<crayon1 >

Layers


Phrase/Layers

Card


Book
Cover


Shadow


Blackout

Layers

Phrase/Layers

Card



Book
Cover



Shadow

Blackout

www.cricut.com

<goodjob>

<a+>

Layers

Phrase/Layers

Card

Book Cover

Shadow



Blackout

INK
INK
<pen&ink>
<pen>


Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout

<satchel>

<backpack>



Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout

<ruler>

<paprclip>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

<lock>

<locker>



Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout

<sack lunch>

<lunchbox>



www.cricut.com

<hmburgr>

<pizzadr>

Layers

Phrase/Layers

Card

Book Cover



Shadow

Blackout

Layers

Phrase/Layers

Card

Book Cover

Shadow


Blackout

www.cricut.com

<hopscotch>



<4square>



Layers

Phrase/Layers



Card

Book Cover

Shadow



Blackout

<bkstack>

<book>



Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout

<gradhat>

<grddplma>





www.cricut.com

<ltrjackt>

<ticket>



<hallpass>

<clock>

Layers

Phrase/Layers

Card



Book
Cover



Shadow



Blackout

www.cricut.com

<laptop>

<desk>

Layers

Phrase/Layers

Card

Book Cover



Shadow



Blackout

<mp3palyr>

<cellphne>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

<flash>

<camera>

Layers

Phrase/Layers

Card

Book Cover



Shadow



Blackout



www.cricut.com

<ribbon>

<#1 ribbon>

Layers

Phrase/Layers

Card

Book Cover



Shadow



Blackout

<drvlcnse>

<lrnpermt>



< keys >

< car >

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

<honrroll>

<reprtcrd>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

<peprally>

<megaphne>



Layers



Phrase/Layers

Card

Book Cover

Shadow



Blackout

<boysrule>

<noboys>



www.cricut.com

<pnttubes>

<brshpllt>


Layers
Phrase/Layers
Card
Book Cover
Shadow
Blackout

<labeqmnt>

<mcroscpe>

Layers

Phrase/Layers



Card



Book Cover



Shadow



Blackout

<singalng>

<recorder>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

<notepapr>

<globe>







www.cricut.com

<calcultr>

<compass>

Layers

Phrase/Layers

Card

Book Cover



Shadow

Blackout

<showtell>

<schlprgm>



www.cricut.com

<doorhngr>



<puzzle>



Layers

Phrase/Layers

Card

Book
Cover

Shadow

Blackout

<keepout>

<biohazard>











<fieldtrip>

<busside>

Layers

Phrase/Layers



Card

Book
Cover



Shadow



Blackout

<homecmng>

<promflwr>

Layers

Phrase/Layers

Card

Book Cover

Shadow

Blackout

www.cricut.com

<kndrgrtn>

<preschl>

Layers



Phrase/Layers

Card

Book Cover



Shadow



Blackout

<2ndgrade>

<1stgrade>



www.cricut.com

<4thgrade>

<3rdgrade>



Layers

Phrase/Layers

Card



Book
Cover



Shadow



Blackout

<6thgrade>

<5thgrade>



<jrhigh>

<mdleschl>

Layers

Phrase/Layers



Card



Book
Cover



Shadow



Blackout

<college>

<highschl>



www.cricut.com

<clckrbkmk>

<mybkmark>



<envelope>

<notecard>



<insertpg>

<bkcover>

Layers

Phrase/Layers



Card

Book Cover



Shadow



Blackout

<instb2&8>

<instb1&4>



For in-depth information about using your Cricut™ cutting system refer to the User Manual included with your Cricut™ machine. If you don't find the answers you need, support is available in the following two ways:

You will find the most current help and documentation on the web site. Find answers to FAQs and Troubleshooting problems any time of the day.
INTERNET: www.cricut.com

Refer to the Customer Support information that came with your Cricut™ machine(s) or call for Customer Support options at:
PHONE: 1-877-7CRICUT (727-4288) Monday–Friday 9:00 a.m.–5:00 p.m., mountain time

29-0289 Locker Talk Handbook
0 93573 10289 9

© 2007 Provo Craft and Novelty, Inc.
All rights reserved/Tous droits réservés
Spanish Fork, UT 84660
Made in China/Fabriqué en Chine
www.provocraft.com • 105406